





ComFlex Edition







PRODUCT (60A BMS) MANUA

Lithium Iron Phosphate (LiFePO4) Battery

PRODUCT OVERVIEW

51.2V 30AH BATTERY

Operating Voltage: 51.2V


Charging Voltage: 57.6±0.8V

Recommended Charge Current: 6A (0.2C)

Max. Continuous Discharge Current: 60A

Max. Continuous Output Power: For Electric Cart[©]: 2000W For Energy Storage: 3072W

① This product is suitable for electric carts that speed lower than 25MI/hour (40KM/hour), such as golf carts, low-speed vehicles (LSV), utility vehicles (UTV), neighborhood electric vehicles (NEV), E-trike and so on. Please ensure that the speed complies with local regulations.





ADDITIONAL COMPONENTS

M8-5/8" (16MM) TERMINAL BOLTS

Recommended terminal torque: 106.2 to 123.9 inch·lbs / 12 to 14 N·m.

The terminal bolts are used to secure multiple cable lugs to a single battery terminal. The bolts can be replaced with **M8** bolts of other lengths based on actual needs.



BATTERY PARALLEL COMMUNICATION CABLE

BATTERY PARAMETERS

Cell Type	LiFePO4
Nominal Voltage	51.2V
Rated Capacity	30Ah
Energy	1536Wh
Internal Resistance	≤40mΩ
Cycle Life	≥4000 times
Battery Management System (BMS) Board	60A
Charge Method	CC/CV
Charge Voltage	57.6±0.8V
Recommended Charge Current	6A (0.2C)
Max. Continuous Charge Current	30A
Max. Continuous Discharge Current	60A
Surge Discharge Current	300A@1 second
Max. Continuous Output Power	For Electric Cart [®] : 2000W For Energy Storage: 3072W

Dimension	L10.24*W7.09*H10.24 inch
	L260*W180*H260 mm
Housing Material	Steel Plate Cold Common (SPCC)
Recommended Terminal Torque	106.2 to 123.9 inch∙lbs / 12 to 14 N∙m
Protection Class	IP65
Temperature Range	Charge: 0°C to 50°C / 32°F to 122°F
	Discharge: -20°C to 60°C / -4°F to 140°F
	Storage: -10°C to 50°C / 14°F to 122°F
Low Temperature Charging Protection (LTCP) Function [®]	Yes
Resume Charging Temperature Under LTCP	5°C/41°F (Battery Temperature)
Communication Function [®]	Yes (RS485 CAN)

- ① This product is suitable for electric carts that speed lower than 25Ml/hour (40KM/hour), such as golf carts, low-speed vehicles (LSV), utility vehicles (UTV), neighborhood electric vehicles (NEV), E-trike and so on. Please ensure that the speed complies with local regulations.
- ② This battery supports Low Temperature Charging Protection (LTCP), where the BMS stops battery charging when the battery temperature falls below $0^{\circ}\text{C}/32^{\circ}\text{F}$ and resumes charging when the temperature rises above $5^{\circ}\text{C}/41^{\circ}\text{F}$.
- ③ This battery supports both parallel system communication and external specified screen communication.


HOW TO ESTIMATE THE BATTERY CAPACITY

STATE OF CHARGE (SOC)

The battery capacity could be roughly estimated by its <u>resting voltage</u> (<u>not charging /discharging voltage</u> ⁽¹⁾).

Since the voltage of each battery is slightly different, and the voltage measurement is affected by the measuring instrument, ambient temperature, etc., <u>the following parameters are for reference only</u>. The actual SOC of the battery is based on the discharge capacity under load.

<u>Resting Voltage</u>: The voltage is measured after the battery has been disconnected from the charger and loads with zero current, and left alone for 3 hours.



SOC (%)	VOLTAGE (V)
0	40 to 48
25	52 to 52.6
50	52.6 to 52.8
75	53.2 to 53.32
100	≥53.32 ^②

- ① Based on the characteristics of LiFePO4 batteries, the voltage measured by all LiFePO4 batteries during charging/discharging is not the real voltage of the battery. Therefore, after charging/discharging and disconnecting the battery from the power source, the voltage of the battery will gradually drop/increase to its real voltage.
- ② After this battery is protected from overcharge, the tested battery voltage (not the real voltage) will be lower than the real voltage. To calculate the SOC (%), add 0.5V to 0.7V to the tested battery voltage.

PARALLEL CONNECTION


THE PREMISE OF CONNECTION

To connect in parallel, batteries should meet the below conditions:

- a. identical batteries with the same battery capacity (Ah) and BMS (A);
- b. from the same brand (as lithium battery from different brands has their special BMS);
- c. purchased in near time (within one month).


LIMITATION FOR SERIES/PARALLEL CONNECTION

Support connecting <u>up to 8 identical batteries in parallel</u> for up to 48V(51.2V) 240Ah battery system.



WHAT TO DO WHEN THE BATTERY STOPS WORKING?

When the battery



It has 85% chances that BMS has shut it off for protection, and you could try **one of below ways** to activate the battery.

GENERAL STEPS

If the BMS has cut off the battery for protection, follow the below steps to activate it.

Step Cut off all the connections from the battery.

2 <u>Leave</u> Then

Leave the battery aside for 30mins.

Then the battery will automatically recover itself to normal voltage (>40V) and can be used after fully charged.

If the battery is unable to recover itself after the above steps, please try activating by **one of the below two methods**. After activated (voltage > 40V) and fully charged by the normal charging method, it can be used normally.

Method 1

Use a <u>charger with lithium battery activation function</u> to fully charge the battery.

Method 2

Connect <u>a controller</u> that supports 48V LiFePO₄ battery charging to charge the battery for 3~10s in sunny daytime.

